
OPA

Dante Ceiling Speaker C8130D

Quick Installation Guide



Package List



C8130 Network Ceiling
Speaker (1 pcs)




Card slot cardboard
(1 pcs)


► English ◀

Installation Method

- 1 Use a tool to open a circular installation hole with a diameter of 240mm in the ceiling.




- 1 Connect the PoE+ cable or Ethernet cable and the power supply to the device.
- 2 If you have any external devices, connect them at this time.
- 3 Remove the grille; install the product into the pre-cut hole on the ceiling and tighten the screws; then reattach the grille.
- 4 Ensure that the device is properly installed and securely fixed.



Network Settings

- 1 Connect the PoE+ cable or Ethernet cable and the power supply to the device, and wait for the device to start up.
- 2 Once the device has finished starting, it will broadcast its IP address.
- 3 By default, it is set to DHCP; if the device does not obtain an IP address through DHCP, the default IP address will be 192.168.1.101.
- 4 Enter the device IP address in the address bar of browser to enter the device login interface.
- 5 The default username and password for the device are both "admin."


Interfaces and Instructions




中文

安装方式

- ① 用工具在天花板上开一个直径为240mm的安装圆孔。




- ① 将 PoE+ 线或网线以及电源连接到设备上。
- ② 如果您有使用外接设备，请在此时连接它们。
- ③ 将产品网拆出；按预先开好的孔将产品安装到天花板上，并拧上螺丝；将网重新装上。
- ④ 确保设备安装到位并且牢固可靠。



系统登录导向

- 1 将PoE+线或网线以及电源连接到设备上，等待设备启动。
- 2 设备启动完成后，设备进行IP播报。
- 3 默认为 DHCP，如果设备未通过 DHCP 获取 IP 地址，则默认 IP 地址为 192.168.1.101。
- 4 若要访问设备的登录界面，请直接在网络浏览器的地址栏中输入设备的 IP 地址（通过 DHCP 获取的 IP 地址或默认 IP 地址）。
- 5 设备默认用户名和密码均为“admin”。

接口和说明





OPA Co., Ltd

www.odmpa.com